PiNK
POWERED BY Moss

Clear Sphere

Please read before assemling

PINK PROVIDES:

1 Clear Sphere

YOU PROVIDE:

Site Plan/Event Layout
Plastic Drop CLoth
Extension Cords



* Permormers must have socks on.

Additional Support Please Call:
212-253-6666 or
After Hours: 646-853-3900

1. Please wash hands before handling the costumes. If you have long hair, pull it back into a low bun as it tends to get warm in the costumes.

2. Lay our the drop cloth near the final location. Remove the Clear Sphere from its box and place it onto the drop cloth. The costume will be folded and deflated. Unfold as much as possible.



The Sphere needs a 10′ x 10′ x 10′ area.

3. There will be a cord attached to a fan on the costume. Plug the cord into an outlet or extension cord, and watch the Sphere as it inflates.



As air fills the Sphere, continue unfolding any creases that may be stuck together.

4. When the Sphere is fully inflated, you will see a zipper in its back. It opens to the outside. Only unzip when entering or exiting the costume.



Performers should only wear socks or Pink Inc. booties when inside the costume. Shoes can rip the costume.

Any and all rights (including, without limitation, copyright, design patent, use patent and trademark) in and to all designs, concepts, renderings, or graphics (collectively, "Design") represented in this document were created by Moss Inc. and remain the sole and exclusive property of Moss Inc. Use of any such Design by the recipient without required purchase is strictly prohibited. ©2010

5. Movement should be appropriate to the event, whether fun and playful or simple and elegant. In any situation, please remember that the Sphere is connected to a cord that keeps the costume inflated.

Often times Pink Inc. places a Diva or a Nude inside the costume. Follow the movement instruction for the Diva inside the Clear Sphere. The combination of the two creates an unforgettable performance.





SAFETY PRECAUTIONS:

Keep loose, lightweight objects away from the fan. These items can get stuck and damage the costume.

When performing, be sure not to bring any sharp objects in or around the Clear Sphere.

The performer needs a spotter when entering and exiting the costume. The spotter does not need to be part of the performance but should remain in close proximity to the performer at all times.

Do not unplug the Sphere until the performer is out of the costume and the zipper is closed.



Any and all rights (including, without limitation, copyright, design patent, use patent and trademark) in and to all designs, concepts, renderings, or graphics (collectively, "Design") represented in this document were created by Moss Inc. and remain the sole and exclusive property of Moss Inc. Use of any such Design by the recipient without required purchase is strictly prohibited. ©2010